

FITTING INSTRUCTIONS

RP59 - Window & Door Weather Strip



DIRECTIONS FOR MODEL RP59

All surfaces must be clean, smooth, and if painted well cured.

Note: Self-adhesive seals will not stick to oil-rub finishes.

1. Use a pin to carefully separate backing from adhesive.
2. Separate twin rubber weather strip to form single strip.
3. Apply seal on Latch Side and Hinge Side as illustrated.

