


Install Instructions

Sliding Door Pull



*Image used for illustration purposes only.

iver


Tradco Hardware Pty Ltd
trading as Iver
ACN 008 154 041
ABN 18 008 154 041

Australia
14—16 Stepney Street
Stepney, South Australia 5069
P. +61 (0)8 8362 1133
info@iver.com.au
iver.com.au

New Zealand
21 Downing Street
Takaro, Palmerston North 4412
P. +64 (0)6 359 0008
info@iver.co.nz
iver.co.nz


1. Marking the Door

- 1.1. Mark the edge of your door at the desired height of your pull handle.
- 1.2. Affix provided template to door and mark appropriate points for drilling.




2. Preparing the Door

- 2.1. As per template, drill 2mm pilot holes at the top and bottom of the pull half-way through the door. Complete from the other side to avoid splitting door. Re-drill pilot holes with 10mm drill bit to accommodate tie bolt.




- 2.2. As per template, using your preferred method create a W36mm X H140mm cavity through door.




3. Install Pull Handles

- 3.1. Insert pulls on either side of the door.




- 3.2. Insert tie bolt and cut to size as necessary.
- 3.3. Install pulls securing them with tie bolts.




4. Install Edge Pull – Marking the Door

- 4.1. Mark the edge of your door at the desired height of your edge pull.




5. Preparing the Door

- 5.1. Using preferred method create a W25mmxH42.5mm cavity to a minimum depth of 20mm on the door edge.




- 5.2. Remove dust and insert dust box.
5.3. Place edge pull over cavity and mark around the edges with a Stanley knife.




- 5.4. Using your preferred method create a 3mm recess to accommodate face plate.

Sliding Door Pull Edge




6. Installing Edge Pull

- 6.1. Insert the edge pull face plate.




- 6.2. Drill two 2mm pilot holes for face plate screws at 6 and 12 o'clock and Install screws.
6.3. Tighten manually with a screwdriver.


Edge Pull



Included:



Not Included:



IMPORTANT!

The screws provided with Iver products are made from solid brass. This allows finishes to be matched as closely as possible and prevents the possibility of screws rusting in coastal areas. Please note that screws require **pre-drilling**.

Please take extra care when fitting.




EDGE PULL DRILL TEMPLATE



Caution


- * Please take time to read the installation guides in full, prior to commencing any work on the door.
- * Check the template is the appropriate template required for the installation
- * Check the scale of the template is correct, using the scale check. If the template is not to scale, please contact your distributor.

Scale Check



Trim here if required

Trim here if required




SLIDING PULL NON-LOCKING AND PRIVACY FUNCTION DRILL TEMPLATE

Align with door edge

EDGE OF DOOR

Align with door edge



205mm

A

Ø 10mm

155mm

Guideline

Align guideline with template A & B

60mm backset

60mm backset

36mm

iver

Align with door edge

EDGE OF DOOR

Align with door edge

Trim here

Trim here

Trim here

Scale Check

50mm

50mm

Centre of door edge

35mm

38mm

42mm

B

14mm

23mm

Guideline

Centre of door edge

Align with left hand side of door edge