

MORE THAN JUST QUALITY – AN EXPERIENCE™



ASTRON
LUXE
INTEGRATED
PRIVACY SET

Component: 1 Pair Integrated Privacy Set
(with push button on rose) & 1x Integrated Privacy Latch

Description:


- 20 years warranty – your peace of mind
- Superb Quality – feel it and then you'll know
- Corrosion resistant sacribond & micronized Finishes
- Heavy duty construction
- 55mm rose – concealed Fixing
- Through Door bolts for a secure Fix that won't twist out of square
- 15 excellent architectural, ergonomic designs
- Fire rated for 1 hour

Available Set:

- Lever Set
- Passage Set
- Separate Privacy Set
- Integrated Privacy Set
- Dummy Set
- Entrance Set

Available Finish:

- Brushed Nickel / Chrome Plate



Note: Measurements are in mm

1 300 926 321 

sales@zanda.com.au 

www.zanda.com.au 

MORE THAN JUST QUALITY — AN EXPERIENCE™


ASTRON
LUXE

INTEGRATED PRIVACY SET


Component: 1 Pair Integrated Privacy Set
(with push button on rose) & 1x Integrated Privacy Latch

1. Measure the door thickness and mark the centre at the desired height for the latch.

2. Drill a 25mm (1") diameter hole through the door edge to a depth of at least 80mm. Ensure this hole is square to the door.



3. Mark the face of the door each side for drilling a 25mm diameter spindle hole. The centre of the spindle hole will need to be 60mm from the door edge (backset). For clean cut-outs, drill from both sides, meeting in the middle of the door. Mark and drill two 6mm screw holes at 21mm above and below the centre of the spindle hole. Mark and drill one 6mm privacy pin hole at 21mm from the centre of the spindle hole towards the latch.




4. To change the handing of the latch, remove the outer faceplate, pull and rotate the latch tongue 180 degrees.

5. Insert the latch. scribe around the faceplate, remove, then chisel out recess to enable the latch faceplate to sit flush with the door edge.

6. Remove any loose saw dust and insert the latch. attach the faceplate and secure with the wood screws provided.


7. Remove the o-ring from the spindle. Insert the spindle into the latch so an even amount protrudes on each side of the door and slide the o-ring back onto the spindle.



8. Pull off rose covers from the levers and unscrew the bolts from the threaded sleeves-

9. Insert the threaded sleeves through the oval holes in the back of the rose at two vertical positions. Screw the short bolts from the top of the rose through into the threaded sleeves.

10. Slide the handle over the spindle and press against the door.




Note: The grubscrews may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used.

11. Slide the handle on the opposite side of the door over the spindle and tighten the long bolts through into the rose.

12. Press the rose covers onto the handles and ensure the integrated privacy pin hole is lined up. Tighten the grubscrews on the side of the levers onto the spindle for each side of the door. For the square rose tighten the grubscrews on the side of the rose.

13. Insert the integrated privacy pin through the rose and into the threaded slot on the latch.

14. Close the door against the frame and mark the latch position for fitting of the striker.
15. Router or chisel so the striker fits flush, allowing for the plastic dustbox behind the striker.
16. Secure the striker with the wood screws provided. Test the door and if necessary, adjust the striker anti-rattle tab to take up any rattle.



Note: Measurements are in mm

1 300 926 321

sales@zanda.com.au

www.zanda.com.au